Philips
DVD lens cleaner

Brush system

SVC2520W

Clean and protect your DVD player

Regular cleaning of your DVD player's lens ensures optimum performance of your equipment. It is important to keep a DVD player optical laser lens clean and dust free. This dry-brush system safely removes dust, debris and other contaminants.

Maintain original sound and video quality

- Safe dry brush cleaning system

Easy to use

- Voice instructions in 14 languages

PHILIPS

DVD lens cleaner
Brush system

SVC2520W/97

Specifications

Storage Media
- Supported formats: DVD-ROM, DVD/R, DVD/RW

Inner Carton
- Gross weight: .8 kg
- Inner carton (L x W x H): 20 x 11 x 16 cm
- Nett weight: .12 kg
- Tare weight: .68 kg

Outer Carton
- Gross weight: 9.4 kg
- Outer carton (L x W x H): 42 x 21.5 x 49 cm
- Nett weight: 1.44 kg
- Tare weight: 7.96 kg

Packaging dimensions
- Packaging dimensions (W x H x D): 14 x 19 x 1.4 cm
- Gross weight: .12 kg
- Nett weight: .02 kg
- Tare weight: .1 kg

Highlights

Dry brush system
The dry brush cleaning system safely removes dust, debris and other contaminants from the CD/DVD players laser lens, leaving it clean and performing optimally.

Voice instructions
The voice instructions on this easy to use CD lens cleaner guide you through the cleaning process in one of the 14 languages provided.

Issue date 2014-02-07

Version: 1.1.4

12 NC: 8670 000 35912
EAN: 87 12581 38596 5

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com